

Analysis of Carbon Equivalents in Steel Components

Using the Niton Apollo Handheld LIBS Analyser

Application

The weldability of a steel is primarily influenced by its carbon content. Additionally, the contribution of other elements, such as manganese (Mn), chromium (Cr), molybdenum (Mo), vanadium (V), copper (Cu), nickel (Ni), and silicon (Si) can also impact its carbon equivalence (CE). These additional elements add up in scrap fed electric arc furnace steels that now predominate the market and carry over into finished goods.

Carbon equivalence was originally developed to assign a numerical value for a given steel composition indicating the carbon content which would contribute to an equivalent level of hardenability for that steel. Even further, carbon equivalence represents the contribution of the materials composition to cold-cracking (hydrogen cracking) susceptibility of the steel.

In welding, carbon equivalent calculations are used to predict heat affected zone (HAZ) hardenability. By understanding any differences in chemistry through the carbon equivalence calculation, it can be determined if the properties of two materials being joined together via a filler metal component are compatible for the process. If the components are too dissimilar, or if the carbon equivalent approaches a higher, undesirable value (Table 1), then special precautions may be needed prior to and during the welding process.

Welding precautions may include prescriptive heat treatment, use of low hydrogen electrodes, and controlling heat input.

Many of these guidelines are published in the NACE (National Association of Corrosion Engineers) standards.



Carbon equivalence (CE) is an essential calculation prior to performing welding.

(NACE MR0175/ISO 15156 and NACE MR0103/ISO 17945). These standards were developed for offshore, petrochemical, and natural gas applications where carbon steels in the presence of hydrogen sulphide (H₂S, sour service) are susceptible to sulphide stress cracking (SSC) or hydrogen stress cracking (HSC).

There are two commonly used equations for expressing carbon equivalence developed by the International Institute of Welding (IIW), and American Welding Society (AWS).

International Institute of Welding (IIW)

$$CE = C + Mn/6 + (Cr + Mo + V)/5 + (Cu + Ni)/15$$

American Welding Society (AWS)

$$CE = C + (Mn + Si)/6 + (Cr + Mo + V)/5 + (Cu + Ni)/15$$



Application Note

Niton Apollo Handheld LIBS Analyser

There's a new tool available to professionals performing material analysis. The Thermo Scientific™ Niton™ Apollo™ handheld LIBS analyser utilises Laser Induced Breakdown Spectroscopy (LIBS) to perform inspection of critical assets and carbon equivalent calculations. Weighing just 6.4 lbs. (2.9 kg.), the Niton Apollo specialises in measuring carbon content in a convenient, portable form factor – eliminating the need for bulky Optical Emission Spectroscopy (OES) carts in many situations.

Featuring an effective laser and high purity argon purge, the Niton Apollo delivers lab quality results in about 10 seconds. In addition to calculating carbon equivalents, users can identify alloy grades, perform advanced averaging, and program pseudo elements. Data is displayed in real time, to enable fast and efficient decision making.

Test Method and Results

Similar to other elemental technologies, sample preparation is required when using the Niton Apollo to ensure the most reliable performance and results.

Common CE Value Classifications	
Carbon Equivalent (CE)	Weldability
Up to 0.35	Excellent
0.36-0.40	Very Good
0.41-0.45	Good
0.46-0.50	Fair
Over 0.50	Poor

Table 1

Sample	CE-IIW	CE-AWS	C	Mn	Cu	Si	Ni	Cr	Mo	V	Ti	Al
X65	0.287	0.335	0.049	10.61	0.118	0.286	0.117	0.090	0.056	0.081	0.005	0.038
X65	0.306	0.352	0.042	1.209	0.118	0.279	0.095	0.087	0.064	0.087	0.005	0.024
X65	0.291	0.338	0.040	1.134	0.125	0.277	0.105	0.091	0.061	0.085	0.005	0.030
X65	0.290	0.338	0.042	1.116	0.118	0.284	0.112	0.096	0.065	0.077	0.005	0.0314
X65	0.300	0.346	0.039	1.196	0.116	0.276	0.094	0.080	0.068	0.088	0.005	0.028
X65	0.294	0.341	0.034	1.171	0.113	0.280	0.102	0.092	0.078	0.083	0.005	0.030
X65	0.278	0.326	0.039	1.091	0.124	0.289	0.106	0.090	0.049	0.069	0.006	0.032
X65	0.295	0.340	0.046	1.127	0.116	0.2783	0.109	0.087	0.063	0.081	0.005	0.034
X65	0.282	0.333	0.041	1.078	0.117	0.310	0.107	0.095	0.059	0.075	0.004	0.038
X65	0.280	0.325	0.36	1.115	0.110	0.275	0.098	0.089	0.053	0.079	0.005	0.034
AVG	0.290	0.337	0.041	1.130	0.118	0.283	0.105	0.090	0.062	0.080	0.005	0.032
STDEV	0.009	0.008	0.004	0.049	0.004	0.011	0.007	0.005	0.008	0.006	0.000	0.004
RSD	3.1%	2.4%	10.7%	4.3%	3.8%	3.8%	7.1%	5.1%	13.1%	7.2%	9.1%	13.7%

Table 2

More information on sample preparation procedures can be found by visiting nitonuk.co.uk/apollo

Several samples of carbon steels used in various applications were chosen for testing using the Niton Apollo. Chemistry and subsequent carbon equivalent calculations are shown using both IIW and AWS formulae as a measure of repeatability testing (Table 2).



Application Note

The performance of the Niton Apollo handheld LIBS analyser demonstrates the ability to accurately and repeatedly capture carbon content, as well as automatically calculate carbon equivalence using a prescribed formula via pseudo element feature. Whether working at heights in a refinery, offshore on an oil platform, or in a pipeline trench, the Niton Apollo is the ideal tool for analysis in many different industries offering the utmost safety and productivity.



01256 397860
info@nitonuk.co.uk
nitonuk.co.uk

Niton UK Ltd, Unit 17-19 The Calvert Centre, Woodmancott, Winchester SO21 3BN

